

# Card Reader Installation Guide

1. Download the software from the **Card Reader** section on <http://photoid.avery.com/support/software/2.x/index.html>
  - a. Click on the link **Card Reader Software** and download **SDK\_Setup.exe** file on your computer

Please download the latest version of the Card Reader Software, so that you have the most optimal capabilities.

2. Follow the steps below to install the card reader driver:
  - a. Plug scanner into USB port of your computer. Windows will find new hardware and prompt you to install the driver.
  - b. Insert the CD provided with the card reader and follow the screens to install the driver.
3. Follow the steps below to install the card reader software:
  - a. Double click on downloaded SDK\_Setup.exe. The software will be installed automatically.

## Note:

- If you are scanning any card for the first time it may ask you to calibrate the reader. Please insert the calibration paper and then click Calibrate.
- Ensure that the card reader is connected to the same USB port where you have installed the driver.
- Connect the card reader to the USB port before starting the Avery Photo ID System.